


EXPLODED DIAGRAM OF BT/18S



MODEL BT/18S PART LIST

DRAWING NUMBER	PART NUMBER	DESCRIPTION	ITEM QTY	DRAWING NUMBER	PART NUMBER	DESCRIPTION	ITEM QTY
1	RH99001	HEX.SOC.HD.SCREW	1	36	RH10110	NOSE COVER B	1
2	RH10422	DEFLECTOR	1	37	RH99008-0	HEX.SOC.HD.SCREW	2
3	RH15840	SEAL	1	38	RH99004	HEX.SOC.HD.SCREW	2
4	RH99006-0	HEX.SOC.HD.SCREW	4	39	RH28340	QUICK RELEASE COVER	1
5	RH1A082	CAP	1	40	RH93009	SPRING PIN	1
6	RH10001	SEAL	1	41	RH10581	NOSE COVER A ASSY.	1
7	RH96005	O-RING	1	42	RH10630	BRACKET	1
8	RH236-06	CAP GASKET	1	43	RH99003-0	HEX.SOC.HD.SCREW	3
9	RH10008	SPRING	1	44	RH97001	SPRING WASHER	1
10	RH96008	O-RING	2	45	RH10620	BRACKET	1
11	RH1A005	HD.VALVE PISTON	1	46	RH10570	MAGAZINE COVER	1
12	RH1A340	CAP COLLAR	1	47	RH10560	MAGAZINE	1
13	RH1A321	HD.VALVE ASSEMBLY	1	48	RH99002-0	HEX.SOC.HD.SCREW	2
14	RH96078	O-RING	1	49	RH10610	LATCH PLATE	1
15	RH10330	PISTON RAM ASSEMBLY	1	50	RH10600	PUSHER	1
16	RH96050	O-RING	1	51	RH52350	SHAFT	1
17	RH1A031	CYLINDER BUSHING	1	52	RH10018	SPRING	1
18	RH96036	O-RING	1	53	RH10020	STEEL PLATE	1
19	RH96038	O-RING	1	54	RH92001-0	LOCK NUT	1
20	RH10310	CYLINDER	1	55	RH10660	PIN	1
21	RH28050	BUMPER	1	56	RH10590	LATCH BRACKET	1
22	RH236-62-2	GUN BODY	1	57	RH95001	E-RING	1
23	RH236-22	RAM GUIDE	1	58	RH15460	SPRING	1
24	RH236-08	CYLINDER BUSHING	1	59	RH10640	LATCH	1
25	RH10350	SAFTY ASSEMBLY	1	60	RH10051	TRIGGER VALVE W/ O-RING	1
26	RH94002-0	AIR PLUG	1	61	RH10050	TRIGGER VALVE STEM W/O-RINGS	1
27	RH28101	END CAP	1	62	RH10052	TRIGGER VALVE W/ O-RING	1
28	RH96037	O-RING	1	63	RH96074	O-RING	1
29	RH92001-0	LOCK NUT	1	64	RH10046	TRIGGER VALVE	1
30	RH10011	SECONDARY TRIGGER	1	65	RH10048	SPRING	1
31	RH10441	PRIMARY TRIGGER	1	66	RH96010	O-RING	1
32	RH93001	SPRING PIN	1	67	RH10047	TRIGGER VALVE STEM	1
33	RH93004	SPRING PIN	2	68	RH96001	O-RING	1
34	RH236-27	LATCH BRACKET	1	69	RH96004	O-RING	1
35	RH10551	NOSE	1	70	RH10045	TRIGGER VALVE GUIDE	1